

Configuration de votre télécommande

Codes à 4 chiffres pour les marques de téléviseurs, de lecteurs DVD et d'amplificateurs

Marques de téléviseur

A

AR Systems	1257	1263	1400	1402	1466	1478	1809																		
Acer	1434	1764																							
Action	1140	1258	1402	1677																					
ad notam	1830																								
Admiral	1140	1181	1263	1402	1790																				
Advent	1313	1754																							
Adyson	1270	1402																							
Aeg	1374	1411	1447	1449	1450	1455	1463	1466	1473	1484	1486	1781													
Agath	1596																								
AgfaPhoto	1574	1649																							
Airis	1561	1656	1685	1692	1728																				
Aiwa	1156	1401	1402	1503	1508	1770																			
Akai	1140	1350	1352	1362	1390	1394	1399	1400	1401	1402	1411	1417	1434	1447	1449	1451	1454	1548	1631	1646	1651	1671	1701	1818	
Akira	1399	1707	1772																						
Akura	1140	1263	1402	1434	1449																				
Alba	1145	1146	1263	1299	1302	1382	1394	1402	1406	1675	1721	1752	1787	1790											
Albiral	1402	1785																							
Allstar	1402	1466																							
Alphatronics	1543																								
Alphatronik	1617																								
Altek	1707																								
Altus	1377	1411	1447	1449	1468	1791																			
Amoi	1739																								
Amstrad	1140	1345	1572	1804																					
Andersson	1434																								
Anitech	1140	1263	1270	1400	1402	1466																			
AOC	1402	1698																							
Apro	1688																								

Codes à 4 chiffres pour les marques de téléviseur

Arc En Ciel	1814	1820							
Arcelik	1377	1411	1447	1449	1463	1791			
Arctic	1411	1447	1449						
Arena	1394	1411	1434	1447	1449				
Aristona	1374	1398	1399	1400	1402	1407			
Arthur-Martin	1463	1473	1484						
Astra	1140	1402	1411	1447	1449				
Atec	1311								
Audiosonic	1140	1263	1377	1401	1402	1411	1447	1449	
Aver Media	1709								

B

Bang & Olufsen	1401	1402	1514							
Basic Line	1143	1394	1402	1434	1447	1449	1450	1455	1624	1781
	1787									
Bauer	1181	1265	1399	1402	1822					
Baur	1140	1345	1396	1399	1400	1401				
Baur	1402	1448	1503	1508	1509	1626	1639			
Baysonic	1263									
Beaulieu	1399	1402								
Beko	1377	1394	1402	1411	1447	1449	1450	1451	1463	1464
	1468	1469	1649	1680	1780	1787	1791	1818		
Belson	1387	1413	1434	1515	1547	1554	1585	1600	1651	1652
	1685	1687	1707	1738	1756	1781				
Benq	1684									
Bestar	1140	1402								
Blaupunkt	1145	1146	1399	1400	1402	1429	1463	1473	1484	1686
	1814	1820	1822							
Blue Sky	1145	1146	1339	1382	1394	1402	1411	1413	1434	1447
	1449	1450	1455	1466	1486	1685	1741	1781	1787	1791
Blusens	1544	1545	1577	1578	1579	1580	1581	1604	1608	1612
	1616	1685	1748							
Bosch	1399	1402	1463	1473	1484					
Boxford	1457	1462	1732							
Brandt	1181	1339	1382	1396	1401	1434	1449	1468	1700	1814
	1818	1820	1823	1824						
Brandt Electronique	1814	1820	1823	1824						
Braun	1396	1455	1827							
Brionvega	1401	1402	1476	1784						

Codes à 4 chiffres pour les marques de téléviseur

Brother _____	1263									
Bruder _____	1483									
Bush _____	1145	1146	1254	1259	1263	1302	1374	1377	1394	1395
	1402	1406	1411	1447	1449	1721	1787	1791		

C

Campomatic _____	1636									
Canon _____	1399	1402								
Caratec _____	1649									
Casio _____	1402	1466	1603							
Centrum _____	1377									
CGE _____	1140	1790								
Changhong _____	1633	1640	1685							
Charisma _____	1523									
Charpy _____	1660									
CIE _____	1140	1143	1572							
Cinex _____	1450	1455	1466	1486						
Clarivox _____	1402	1782	1789	1811						
Clatronic _____	1140	1402	1411	1447	1449	1790				
Claud _____	1401									
CMX/Commax _____	1559	1597	1689	1690	1691	1705				
Combi _____	1561									
Computec _____	1466									
Condor _____	1140	1402	1466	1790						
Conia _____	1449									
Conic _____	1402	1677								
Conrac _____	1791	1797								
Constructa _____	1400									
Contec _____	1140									
Continental _____	1145	1146	1411	1447	1449					
Continental Edison _____	1145	1146	1814	1820	1823					
Crosley _____	1402	1677								
Crosswood _____	1394	1411	1447	1449	1468					
Crown _____	1140	1181	1377	1401	1402	1411	1447	1449	1469	1660
	1685	1785	1791							
Curtis _____	1258	1402	1479	1624	1639	1790				
Cybercom _____	1377									
Cyberpix _____	1434									

Codes à 4 chiffres pour les marques de téléviseur

D

Daewoo _____	1140	1143	1150	1151	1152	1154	1155	1156	1374	1377
	1402	1404	1406	1447	1449	1463	1466	1688	1757	1833
Dalco _____	1772	1773								
Dangaard _____	1573	1574	1576	1611	1612	1651	1707	1713		
Dantax _____	1377	1382	1402	1411	1447	1449				
Davis _____	1401									
Daytek _____	1758									
DCE _____	1394	1402	1411	1447	1449					
Decca _____	1402	1430	1466	1486	1803					
Dell _____	1776									
Denon _____	1162	1508	1662	1671	1765					
Denver _____	1140	1558	1573	1609	1613	1701				
Diboss _____	1465	1466								
Digihome _____	1382	1434								
Digiline _____	1400	1787								
Digiloc _____	1551	1640								
Digital _____	1377	1449								
Digital+ _____	1377									
Digitech _____	1345	1394								
DLD _____	1659									
Dmtech _____	1382	1394	1434	1436	1482	1568	1718			
DQT _____	1586	1778								
Dual _____	1140	1345	1377	1399	1402	1403	1405	1406	1411	1434
	1449	1721								
Dumont _____	1790	1793								
Durabrand _____	1377	1394	1411	1434	1447	1449				
Dynatron _____	1729									
DYNEX _____	1841	1842								

E

Easy Touch _____	1685									
Ecron _____	1394	1402	1449							
Elbe _____	1377	1382	1394	1400	1402	1411	1434	1449	1450	1455
	1456	1463	1466	1556	1563	1685	1731	1734	1758	1799
Elbit _____	1401	1402	1408							
Electric Mirror _____	1753									
Electrohome _____	1434	1624	1677							

Codes à 4 chiffres pour les marques de téléviseur

Elekta	1140	1263	1377							
Elektronika	1402									
Elemis	1394	1434	1466	1486						
Elfunk	1382	1394								
Elin	1140	1402	1466							
Elite	1258	1402	1624	1639						
Elmak	1402	1414	1415	1786						
Elman	1793	1818								
Elta	1140	1402	1411	1447	1449					
E-Max	1692	1758								
Emerson	1394	1402	1411	1447	1449	1450	1455	1729	1787	1811
E-motion	1685	1686								
Enox	1651									
Erres	1374	1398	1399	1400	1402	1499	1823			
Esc	1140	1402								
Essentiel B	1382	1385	1402	1434	1629	1651	1702	1756	1781	
Eternity	1686	1758								
Etron	1140	1402								
Euroline	1377	1394	1402	1411	1434	1447	1449	1713		
Europa	1411	1447	1449							
Europhon	1402	1663	1793	1799						
Excelsior	1374									

F

Fenner	1140	1377	1402	1411	1447	1449	1787			
Ferguson	1166	1339	1341	1370	1372	1393	1399	1400	1401	1402
	1466	1503	1508	1509	1626	1639	1643	1675	1676	1677
	1680	1686	1717	1802	1803	1818	1820	1822	1823	1824
	1829									
Finlandia	1624	1824								
Finlux	1140	1350	1351	1352	1354	1356	1358	1362	1364	1382
	1394	1399	1400	1402	1411	1430	1434	1447	1449	1456
	1466	1486	1761	1784	1790	1794				
First Line	1140	1143	1377	1394	1400	1401	1402	1411	1434	1447
	1449	1466	1503	1624	1705	1787	1791			
Fisher	1148	1508	1624	1626	1788	1795				
Force	1758									
Formenti	1401	1402								
Frontech	1140	1263	1824							
Fujitsu	1213	1510	1791	1797						

Codes à 4 chiffres pour les marques de téléviseur

Fujitsu Siemens _____	1615									
Funai _____	1140	1263	1377	1389	1390	1394	1411	1434	1447	1449
	1510	1574	1729	1779						

G

Galaxis _____	1402	1790								
Galeria _____	1140									
GBC _____	1140	1402								
GEC _____	1400	1402	1508	1677						
Geloso _____	1140									
General _____	1140	1463	1473	1484	1772					
Gericom _____	1311	1745	1791							
Goldhand _____	1140									
Goldstar _____	1138	1140	1145	1146	1258	1263	1284	1399	1401	1402
	1404	1418	1447	1449	1452	1466	1571	1614	1615	1677
	1798									
Goldy _____	1772									
Goodmans _____	1140	1143	1154	1156	1160	1254	1288	1298	1302	1339
	1377	1378	1382	1394	1400	1401	1402	1404	1410	1411
	1434	1447	1449	1466	1472	1553	1570	1601	1646	1651
	1685	1714	1758	1787	1791					
GPM _____	1140									
Graetz _____	1377	1382	1394	1411	1413	1434	1449	1626		
Gran Prix _____	1466	1486	1703	1704	1705					
Granada _____	1166	1181	1208	1354	1355	1362	1374	1399	1400	1401
	1402	1407	1430	1624	1639	1671	1675	1676	1803	1824
Grandin _____	1377	1382	1394	1402	1411	1434	1447	1449	1571	1731
	1787	1791								
Grundig _____	1141	1145	1146	1214	1215	1216	1217	1218	1299	1377
	1387	1399	1400	1402	1407	1435	1438	1449	1463	1469
	1473	1474	1484	1485	1513	1601	1602	1614	1721	1758
	1781	1783	1822							
Grunkel _____	1394	1434	1685							

H

H&B _____	1394	1791								
Haier _____	1173	1261	1264	1269	1407	1602	1624	1686	1698	1840
Hannspree _____	1621	1736								
Hanseatic _____	1140	1154	1156	1399	1402	1406	1411	1449	1464	1466
	1784	1798								

Codes à 4 chiffres pour les marques de téléviseur

Hantarex	1140	1401	1402	1648						
HB	1377	1394	1449							
HB Ingelen	1394	1447								
HCM	1140	1263								
Hinari	1140	1402	1466							
Hisawa	1449									
Hisense	1705	1706								
Hitachi	1154	1156	1181	1350	1354	1382	1394	1402	1404	1406
	1407	1419	1429	1430	1434	1626	1639	1662	1663	1664
	1665	1667	1668	1669	1670	1671	1672	1673	1674	1675
	1676	1677	1678	1679	1680	1681	1682	1699	1763	1814
	1823									
Hitachi Fujian	1662									
Höher	1377	1394	1402	1434	1447	1449				
Home Electronics	1732	1781								
Horizont	1402	1411	1447	1449						
HQ	1402									
Humax	1149	1694	1695	1696	1744					
Hyper	1140	1402								
Hypson	1140	1263	1402	1411	1413	1434	1449			
Hyundai	1153	1172	1260	1261	1377	1382	1411	1447	1449	1474
	1707	1754	1759	1760	1772	1777	1781			

|

ICE	1140	1263	1402							
Iekei	1599									
Ikusi	1458									
Imperial	1401	1402	1474	1595	1631	1632	1790			
Indesit	1822									
Infratex	1262	1303	1402	1406	1766	1771	1781	1786	1787	1805
	1809	1810								
Ingelen	1411	1447	1449	1731	1780					
Ingersoll	1140									
Inno Hit	1140	1401	1402	1413	1434					
Insignia	1838	1841								
InterACTV	1443									
Interbay	1140									
Interbuy	1263	1270								
Interfunk	1399	1400	1401	1402	1626	1790	1820			
Intertronic	1402									

Codes à 4 chiffres pour les marques de téléviseur

Intervision _____	1140	1263	1270	1400	1762	1798					
Ipure _____	1542	1631	1649	1758							
Irradio _____	1140	1377	1401	1402	1447	1449	1466				
Iskra _____	1411	1447	1449								
ISP _____	1374										
ITS _____	1140										
ITT _____	1140	1181	1339	1350	1354	1362	1399	1402	1411	1434	
	1447	1449	1463	1473	1484	1624	1626	1721	1794	1814	
ITV _____	1263	1466									

J

JDB _____	1732										
Jetpoint _____	1258	1399	1402								
John Lewis _____	1591										
JVC _____	1171	1182	1183	1184	1185	1186	1187	1188	1189	1190	
	1401	1402	1615	1624	1794						

K

Karcher _____	1140	1377	1401	1402	1466	1486	1799				
Kendo _____	1140	1339	1382	1390	1394	1402	1432	1434	1447	1449	
	1466	1721	1731	1784	1815						
Kenmark _____	1378	1686									
Kenstar _____	1592	1654									
Kenwood _____	1602	1606									
Keymat _____	1312	1594	1639	1661							
Kishu _____	1707										
Kneissel _____	1143	1402	1404	1563	1731	1787	1789				
Konka _____	1159	1267	1767								
KOPERNIKUS _____	1402	1636									
Kortek _____	1747										
Kotron _____	1551										
Kriminal Forsorgen _____	1453										
KTC _____	1756										

L

Latona _____	1744										
Lavis _____	1143	1402	1789								

Codes à 4 chiffres pour les marques de téléviseur

LCD	1569									
Lenco	1140	1141	1143	1158	1263	1402	1406	1449		
Lenuss	1293									
Level	1711									
LG	1402	1434	1447	1449	1452	1466	1571	1602	1603	1606
	1614	1615	1619	1654	1808					
Lifetec	1140	1143	1263	1394	1402	1406	1411	1449	1466	1509
	1787									
Listo	1382	1394	1434							
Lodos	1394									
Loewe	1208	1381	1384	1392	1396	1399	1401	1402	1423	1426
	1446	1455	1787							
Logik	1402	1601	1605	1654	1717					
Logix	1686									
Luma	1140	1402								
Lumatron	1390	1394	1568	1707	1787					
Luxor	1140	1350	1352	1354	1356	1358	1359	1364	1382	1394
	1402	1413	1430	1434	1461	1470	1794			

M

M Electronics	1140	1354	1356	1358	1362	1364	1402	1818		
Magasin	1434	1615								
Magnadyne	1140	1401	1402	1466	1790	1793				
Magnafon	1402	1793	1799							
Magnasonic	1181	1402	1466	1624						
Magnavox	1400	1402	1431	1677						
Magnum	1377	1402	1411	1447	1449	1450	1455	1481		
Manhattan	1382	1394	1434							
Marantz	1374	1398	1399	1402	1409	1662				
Mark	1143	1394	1401	1402	1411	1447	1449	1791		
Mascom	1466	1486								
Matsui	1140	1145	1146	1156	1254	1302	1304	1306	1307	1309
	1382	1394	1466	1510	1572	1601	1624	1643	1717	1721
	1723	1725								
Maxwell	1791									
Mcperson	1472									
Media Station	1644									
Media TV	1406									
Medialine	1831									

Codes à 4 chiffres pour les marques de téléviseur

Medion _____	1350	1351	1377	1394	1402	1406	1411	1434	1447	1449
	1450	1455	1466	1468	1480	1566	1601	1646	1787	1791
	1797									
Melbox _____	1782									
Melectronic _____	1354	1356	1357	1362	1411	1447	1449			
Memorex _____	1263	1475	1624							
Memory _____	1434									
Metz _____	1210	1318	1365	1366	1367	1368	1369	1394	1399	1402
	1434	1466	1540	1541	1787	1791	1822	1839		
Micromaxx _____	1394	1449	1781							
Microspot _____	1382	1641								
Minerva _____	1145	1146	1217	1645						
Minsonic _____	1141									
Mirage _____	1447	1449								
Mirai _____	1505	1510	1567	1735						
Mitsai _____	1686									
Mitsubishi _____	1140	1165	1166	1167	1168	1169	1394	1399	1402	1404
	1407									
Mivar _____	1710	1800								
MTC _____	1258	1401								
Multichoice _____	1438	1730	1775	1828						
Multitech _____	1140	1401	1402	1466						
Mustek _____	1656									
Mx Onda _____	1253	1453	1466	1561	1655					

N

Naim _____	1439									
National _____	1205	1399	1402							
NEC _____	1140	1258	1311	1589	1590	1742	1743	1744		
Neckermann _____	1140	1182	1399	1400	1401	1402	1406	1447	1449	1466
	1499	1503	1508	1509	1721	1722				
NEI _____	1401	1402	1811							
NEO _____	1141	1144	1377	1411	1447	1449	1768	1769	1772	1781
Neovia _____	1296	1466	1745							
Nevir _____	1597									
Nikkai _____	1263	1377	1402	1411	1449	1639				
Nikkei _____	1411	1447	1449	1592	1707					
Nikko _____	1466	1812								
Nissan _____	1258									

Codes à 4 chiffres pour les marques de téléviseur

Nobliko _____	1793									
Nokia _____	1140	1254	1258	1263	1350	1352	1353	1354	1355	1356
	1357	1358	1359	1361	1362	1363	1364	1399	1402	1624
	1626	1721	1790	1794						
Nordmende _____	1181	1307	1339	1377	1401	1404	1411	1447	1449	1594
	1600	1654	1750	1814	1818	1820	1821	1823	1824	1825
Northern Star _____	1744	1746								
Nova _____	1402									
Novox _____	1565	1650								



Oceanic _____	1181	1354	1356	1358	1362	1364	1624			
ODYS _____	1552	1555	1564	1597	1618	1649	1658	1712	1733	1740
	1831	1832								
Okano _____	1140	1801								
Okii _____	1377	1382	1394	1406	1434	1463	1469			
Olympic _____	1140									
Olympus _____	1399	1402								
Onkyo _____	1296									
ONN _____	1377	1688								
Onwa _____	1722									
Opera _____	1402	1420	1707							
Orbit _____	1402									
Orbitech _____	1404									
Orian _____	1773									
Orion _____	1140	1162	1170	1172	1263	1268	1281	1300	1302	1303
	1305	1306	1307	1308	1309	1319	1377	1394	1400	1401
	1402	1413	1417	1434	1447	1449	1450	1455	1509	1572
	1601	1721	1722	1725	1758	1791	1813			
Otake _____	1308	1721	1722							
Otava _____	1428	1466	1477	1478						
Others _____	1394	1402	1692							
Otrum _____	1401									
Otto Versand _____	1140	1181	1208	1345	1396	1399	1400	1402	1406	1466
	1499	1503	1508	1509	1626	1639	1721	1722	1798	1813
	1818	1824								
OVP _____	1459	1460								

Codes à 4 chiffres pour les marques de téléviseur

P

Pacific _____	1307	1447	1449							
Palladium _____	1377	1390	1394	1399	1401	1402	1411	1449	1466	
Panasonic _____	1204	1205	1206	1207	1208	1209	1210	1211	1212	1382
	1399	1400	1401	1402	1508	1822				
Panavision _____	1411	1447	1449	1774						
Pathe Marconi _____	1814	1820								
Peacock _____	1311	1568	1684							
Philco _____	1140	1402	1677	1789	1790					
Philex _____	1399									
Philips _____	1154	1181	1374	1375	1378	1379	1380	1383	1388	1389
	1391	1393	1397	1398	1399	1400	1401	1402	1404	1407
	1412	1426	1466	1492	1493	1494	1495	1496	1497	1498
	1499	1508	1639	1677	1698	1814	1818	1822	1823	1837
Phocus _____	1217	1377	1411	1447	1449	1468	1791			
Phonola _____	1400	1402	1447	1449						
Pioneer _____	1208	1314	1315	1316	1317	1318	1320	1321	1399	1400
	1401	1402	1523	1524	1525	1526	1527	1528	1529	1530
	1531	1532	1639	1823						
PKS _____	1401									
Platinum _____	1715									
Playsonic _____	1377	1394	1411	1447	1449	1469				
Powerpoint _____	1402	1449	1707							
Prandoni Prince _____	1466									
Prima _____	1140	1258	1263	1402	1624	1639				
Princess _____	1140	1377	1447	1449	1451					
Pro Basic _____	1724									
Profectis _____	1434									
Profex _____	1140									
Profilo _____	1440	1450	1455	1456	1466	1483	1486	1640		
Profitronic _____	1402	1466								
Proline _____	1156	1374	1382	1394	1404	1411	1413	1430	1434	1447
	1449	1453	1487	1553	1584	1686	1688	1784		
Promethean _____	1622									
Prosonic _____	1377	1382	1394	1411	1434	1447	1449	1463	1478	1573
	1574	1575	1611	1612	1686	1707				
Protek _____	1434	1685								
Proview _____	1651									
Provision _____	1400	1447	1449	1466						
PYE _____	1398	1399	1400	1401	1402	1407				

Codes à 4 chiffres pour les marques de téléviseur

Q

Quadro _____	1170	1382	1390	1394	1402	1427	1434	1692	1719	1796
Quelle _____	1140	1182	1208	1345	1354	1356	1358	1362	1364	1390
	1394	1396	1398	1399	1400	1401	1402	1423	1466	1499
	1503	1508	1509	1572	1626	1639	1721	1722	1787	1795
	1801	1824	1829							

R

Radiola _____	1374	1393	1398	1399	1400	1402	1407	1492		
Radiomarelli _____	1402									
Radiotone _____	1140	1263	1394	1402	1466	1787				
Radix _____	1626									
RCA _____	1258	1401	1518	1519						
Record _____	1137	1402								
Red Star _____	1466	1486								
Reflexion _____	1649									
Regal _____	1447	1449								
Relisys _____	1651									
RFT _____	1374	1404	1406	1788	1836					
Roadstar _____	1140	1263	1302	1377	1390	1394	1400	1402	1411	1447
	1449	1477	1791							

S

Saba _____	1157	1339	1341	1372	1382	1394	1434	1447	1449	1468
	1700	1793	1814	1818	1820	1823	1824	1826		
Sagem _____	1716	1726	1731							
Saisho _____	1399	1402	1572	1721						
Sakio _____	1140	1263								
Salora _____	1350	1351	1354	1356	1357	1358	1360	1362	1364	1396
	1402	1422	1434	1450	1455	1456	1463	1466	1624	1631
	1649	1685	1781	1783	1794					
Sambers _____	1466	1793	1799							
Samsung _____	1140	1141	1147	1148	1176	1258	1263	1266	1283	1284
	1285	1286	1287	1289	1291	1292	1294	1295	1296	1297
	1374	1386	1399	1401	1402	1407	1433	1434	1448	1466
	1472	1473	1488	1489	1490	1491	1500	1639	1685	1801
Sansui _____	1140	1258	1263	1399	1402					
Sanyo _____	1140	1382	1394	1434	1447	1449	1466	1486	1620	1623
	1624	1625	1626	1627	1643	1788	1795			

Codes à 4 chiffres pour les marques de téléviseur

Scansonic	1449	1515	1516							
Schaub Lorenz	1377	1394	1411	1434	1447	1449	1463	1469	1587	1631
	1649	1707	1791							
Schneider	1140	1254	1263	1345	1373	1374	1382	1393	1394	1398
	1399	1400	1401	1402	1406	1407	1408	1411	1419	1420
	1424	1434	1442	1447	1449	1450	1455	1456	1465	1466
	1472	1481	1486	1492	1787					
Scientific Labs	1402	1456								
Scott	1434	1550	1598	1613	1756					
Sea	1434									
SEC	1254									
SEG	1140	1263	1382	1390	1394	1395	1402	1406	1413	1434
	1441	1449	1463	1509	1649	1710	1787	1788		
Seleco	1400	1402	1443	1784	1806	1814	1815	1824	1828	
Sencor	1377	1463	1631	1707						
Sentra	1639									
Sharp	1174	1175	1176	1177	1178	1179	1180	1181	1399	1400
	1402	1434	1531	1630	1639	1671	1680	1698	1699	1818
	1824									
Shintom	1466									
Shintoshi	1466									
Shivaki	1137	1377	1399	1402	1466					
Siarem	1793									
Siemens	1402	1407	1408	1416	1466	1486	1499	1676	1811	1814
	1820									
Siera	1402									
Sierra	1399	1400	1402							
Silva Schneider	1140	1394	1402	1406	1422	1434	1440	1450	1455	1456
	1463	1465	1466	1483	1486	1557	1562	1629	1631	1640
	1649	1686	1703	1704	1705	1781	1783			
SilverCrest	1382	1394	1413	1434						
Singer	1140	1401	1402	1793						
Sinudyne	1307	1377	1399	1401	1402	1404	1417	1447	1449	1468
	1508	1572	1721	1781	1793	1799	1813			
Sky	1265	1313	1560	1583	1601	1737	1758			
Sky Media	1265	1311	1313	1546	1560	1566	1583	1593	1601	1641
	1649	1654	1685	1686	1693	1720	1758			
Skyworth	1181									
Smaragd	1145	1146								
Sogo	1411	1447	1449	1450	1455					
Sole	1142									
SONiX	1641	1758								

Codes à 4 chiffres pour les marques de téléviseur

Sonolor _____	1624									
Sontec _____	1402									
Sony _____	1161	1162	1163	1164	1181	1208	1315	1399	1400	1402
	1434	1499	1500	1501	1502	1503	1504	1506	1507	1508
	1509	1512	1638	1639	1823					
Soundcolor _____	1377	1394	1411	1447	1449	1466	1468	1486	1791	
Spectra _____	1143									
Splash Vision _____	1697									
Star _____	1261	1377	1402	1466	1719	1772				
Star General _____	1773									
Starlite _____	1140	1466								
Starlux _____	1140									
Strato _____	1263	1377	1707							
Sungoo _____	1645									
Sunkai _____	1411	1447	1449	1572	1721					
Sunny _____	1685									
Sunstar _____	1140									
Sunstech _____	1574									
Supertech _____	1140	1402								
Supratech _____	1549	1649	1653	1657	1659	1723	1749			
Sweex _____	1548	1566	1649							
Swisstec _____	1265	1311	1313	1449	1560	1566	1574	1582	1583	1593
	1601	1635	1641	1654	1685	1686	1693	1720	1736	1737
	1745	1755	1758							
Sylvania _____	1402	1729								
Symphonic _____	1729									

T

Tadistar _____	1466									
Tandberg _____	1394	1651	1820							
Targa _____	1296									
Tatung _____	1146	1290	1374	1401	1402	1430	1456	1462	1466	1470
	1478	1486	1680	1803						
Tauras _____	1629									
TCL _____	1340	1434	1520							
TCM _____	1377	1449								
Teac _____	1413	1546								
TEC _____	1140	1143	1811							
Techline _____	1382	1390	1394	1434	1463					

Codes à 4 chiffres pour les marques de téléviseur

Technica	1258	1394	1434	1450	1455	1781				
Technical	1382	1394	1413	1434						
Technics	1205	1208	1401	1402	1503					
Technika	1382	1394	1434	1546	1574	1686	1833			
Technisat	1374	1388	1400	1402	1404	1781	1807	1836		
Technisson	1411	1447	1449							
Technosonic	1402									
Technotrend	1402	1755								
Techwood	1178	1258	1382	1387	1394	1413	1434			
Tecnimagen	1398	1402	1449							
Tecnison	1140	1466								
Teco	1649									
Tekon	1140	1258								
Teleavia	1814	1818	1820	1822	1823					
Teleco	1444									
Telefunken	1339	1362	1371	1372	1376	1382	1389	1394	1402	1434
	1440	1447	1449	1468	1700	1791	1814	1816	1817	1818
	1820	1821	1822	1823	1824	1829				
Teleopta	1140									
Telerent	1401									
Telestar	1140	1404	1456	1466	1486	1820				
Telesystem	1377									
Teletech	1140	1382	1394	1434	1487	1787				
Teleview	1450	1455	1466	1486						
Telra	1466	1486								
Tensai	1140	1399	1401	1402	1447	1449	1451	1466	1468	1791
	1798									
Terra	1389	1602	1683							
Tesco	1686									
Tesla	1377	1402	1411	1445	1447	1449	1466	1468	1786	
Tevion	1377	1382	1394	1406	1411	1447	1449	1466	1486	1593
	1646	1686	1707	1741	1744	1787				
Thomson	1154	1156	1157	1181	1338	1339	1340	1341	1342	1343
	1344	1372	1420	1424	1449	1466	1468	1520	1594	1600
	1654	1686	1700	1802	1814	1817	1818	1820	1822	1823
	1824	1829								
Thorn	1166	1255	1393	1399	1401	1402	1466	1508	1625	1626
	1639	1643	1676	1677	1802	1818	1820	1822	1823	1824
	1826									
Time	1377									
Tokai	1382	1398	1402							

Codes à 4 chiffres pour les marques de téléviseur

Tokyo _____	1147	1258								
Toshiba _____	1140	1156	1209	1217	1258	1284	1299	1301	1302	1377
	1394	1399	1400	1401	1402	1434	1447	1449	1624	1626
	1628	1630	1634	1637	1638	1639	1642	1643	1647	1662
Triax _____	1339	1471								
Trilux _____	1374	1402	1404	1629	1787					
TWF _____	1707	1741								

U

Uher _____	1399	1401	1402	1509						
Ultravox _____	1402									
UMC _____	1311	1546	1560	1566	1574	1601	1641	1649	1654	1685
	1686									
United _____	1302	1377	1382	1394	1402	1411	1434	1447	1449	1566
	1573	1574	1576	1611	1612	1651	1707	1791		
UnityDigitalTV _____	1296									
Universum _____	1140	1263	1350	1351	1362	1390	1394	1395	1399	1400
	1401	1402	1434	1466	1508	1509	1787	1790	1820	

V

Vanguard _____	1140	1434								
Veseg _____	1382	1434								
Vestel _____	1374	1382	1390	1394	1395	1402	1413	1434	1441	1639
	1787									
Videoseven _____	1510	1758								
Videoton _____	1434	1790	1819	1823						
Viewpia _____	1754									
ViewSonic _____	1310	1421	1727							
Vision _____	1140	1447	1449							
Vision Plus _____	1686									
Visual Innovations _____	1686									
Vivax _____	1377	1467	1468	1474	1636	1639	1649	1660	1708	
Vizio _____	1607	1610	1751							
Vogells _____	1599									
Vortec _____	1402									
VOX _____	1425	1434								
Voxson _____	1377	1402	1411	1447	1449	1466				

Codes à 4 chiffres pour les marques de téléviseur

W

Waltham _____	1382	1394	1434							
Watson _____	1140	1390	1394	1402	1411	1434	1447	1449	1583	1646
	1787									
Wattradio _____	1466	1790	1793	1799						
Welltech _____	1447	1449								
Wharfedale _____	1377	1382								
White Westinghouse ____	1394	1399	1402	1408	1426	1624	1790			
Wilson _____	1685									
Windsor _____	1382	1394	1434	1787	1818					
World of Vision _____	1282	1311	1449							

Y

Yalos _____	1741									
Yamaha _____	1639	1666	1671	1672						
Yoko _____	1140	1143	1263	1402	1434	1624	1820			

Z

Zanussi _____	1434	1603								
Zenith _____	1402	1517								

Marques de lecteur DVD

A

Acer	_____	1234						
AEG	_____	1278	1280	1649				
Afreey	_____	1659						
AgfaPhoto	_____	1610						
Airis	_____	1521						
Aiwa	_____	1206	1737	1738				
Akai	_____	1211	1233	1259	1560	1624	1649	1650
Akira	_____	1634						
Akura	_____	1465						
Alba	_____	1205	1206	1259	1473	1514	1622	
All-Tel	_____	1101						
Altek	_____	1636						
Amoisonic	_____	1721						
Amstrad	_____	1259						
Apro	_____	1618						
Arcam	_____	1254						
Arcelik	_____	1266						
Arena	_____	1233						
Aristona	_____	1298						
Arthur-Martin	_____	1280						
Ascomtec	_____	1502						
Audiosonic	_____	1560						
Auvio	_____	1489						
Axil	_____	1257	1260	1522				

B

Bang & Olufsen	_____	1412						
Basic Line	_____	1259						
Baze	_____	1579						
Beko	_____	1266	1273	1275	1610			
Belgacom	_____	1421						
Bellagio	_____	1576						
Belson	_____	1507	1634					

Codes à 4 chiffres pour les marques de lecteur DVD

Blaupunkt _____	1280	1622								
Blue Sky _____	1206	1220	1221	1229	1259	1278	1489	1642	1747	
Blusens _____	1482	1531	1555	1557	1558	1559	1585	1588	1619	
Bosch _____	1280									
Bose _____	1212									
Boxford _____	1450	1674	1675							
Brandt _____	1220	1221	1747							
Brionvega _____	1274									
Bush _____	1149	1206	1237	1259	1486	1514	1524	1537	1541	1560
	1573	1622								

C

Cablecom _____	1298									
Cambridge _____	1267	1463								
Canal+ Canalsatellite _____	1298									
Caratec _____	1612									
CAT _____	1487	1491	1492	1493						
Centrum _____	1259	1492								
CGV _____	1463	1473								
Charisma _____	1426									
Cinemateq _____	1442									
Cinex _____	1278									
Clatronic _____	1537	1649								
Clayton _____	1259									
CMX/Commax _____	1268	1445	1447	1448	1454	1455	1458	1461	1466	1472
	1474	1476	1477	1483	1485	1508	1511	1516	1522	1528
	1567	1613								
Combi _____	1651									
Conceptronic _____	1506									
Conia _____	1573	1721								
Crown _____	1560	1747								
Cybercom _____	1524									
Cyberhome _____	1656	1657	1658							
Cyrus _____	1248	1707								
Cytron _____	1524	1552	1747							

D

Daewoo _____	1100	1102	1103	1114	1120	1321	1449	1618	1752	
Dalton _____	1487									

Codes à 4 chiffres pour les marques de lecteur DVD

Dangaard _____	1555	1556	1585	1636	1648				
Dansai _____	1645								
Dantax _____	1261	1514							
Daytek _____	1575								
DCE _____	1503								
Decca _____	1278								
Denon _____	1109	1110	1111	1112	1134	1164	1165	1166	1168
Denver _____	1499	1537	1556	1585	1624	1647	1649		
Digihome _____	1259								
Digiloc _____	1505								
Digitech _____	1259								
Dik _____	1446	1524							
Dinamic _____	1649								
Dk Digital _____	1524								
Dmtech _____	1233	1277	1540	1653					
DQT _____	1565	1741							
Dragon _____	1524								
Dual _____	1259	1524	1562	1747					

E

eBench _____	1703									
E-Boda _____	1514									
Eclipse _____	1463	1514								
Elbe _____	1233	1259	1261	1271	1461	1462	1478	1517	1525	1530
	1569	1571	1582							
Electrohome _____	1233									
Elemis _____	1278									
Elta _____	1497	1560	1632	1649						
E-Max _____	1456	1459	1461	1623	1720					
Emerson _____	1175									
Encore _____	1659									
Essentiel B _____	1455	1481	1497	1708						
Euroline _____	1257	1648	1649							

F

Ferguson _____	1220	1523	1532	1652	1747					
Final _____	1677									

Codes à 4 chiffres pour les marques de lecteur DVD

Finlux _____	1233	1234	1237	1257	1261	1278	1449	1463
First Line _____	1383	1747						
Fonestar _____	1633	1635						
Fujitsu Siemens _____	1175							
Funai _____	1206	1309	1745	1755				

G

Game _____	1638									
General _____	1280									
Goldbox _____	1298									
Goldstar _____	1175	1181								
Goodmans _____	1104	1272	1501	1514	1537	1560	1648	1747		
Gorenje _____	1350	1546								
GPX _____	1175									
Graetz _____	1257	1261								
Gran Prix _____	1278	1627	1628	1630	1631	1647				
Granada _____	1130									
Grandin _____	1233									
Grundig _____	1134	1175	1178	1205	1206	1240	1259	1275	1280	1303
	1326	1406	1407	1408	1409	1410	1411	1463	1473	1514
	1551	1643	1699	1713	1722					

H

H&B _____	1259	1537								
Hanseatic _____	1273									
Harman/Kardon _____	1667	1669								
HCM _____	1649									
Henß _____	1259									
Himage _____	1453	1486								
Hitachi _____	1233	1234	1261	1663	1664	1665	1666	1731		
Höher _____	1259	1446								
Home Electronics _____	1449									
Hoyo _____	1564									
Hyundai _____	1636									

I

Imperial _____	1708									
Ingelen _____	1649									

Codes à 4 chiffres pour les marques de lecteur DVD

Ipure_____ 1610 1709
ISP_____ 1206 1298
ITT_____ 1217 1234 1280

J

Jamo_____ 1255 1570
Jeutech_____ 1488
JMB_____ 1206
Jocel_____ 1608
JVC_____ 1113 1114 1115 1116 1117 1118 1119 1120 1121 1122
 1123 1124 1125 1126 1127 1128 1129 1162 1200

K

Karcher_____ 1278
Kendo_____ 1220 1221 1234 1259
Kenmark_____ 1264 1617
Kenwood_____ 1134 1138 1161 1175 1298 1566 1678 1679 1680 1681
 1682
Kiirro_____ 1608 1609
Kingavon_____ 1537
Kiss_____ 1246 1252 1262
Koda_____ 1537
Konka_____ 1536
Koss_____ 1747
Kotron_____ 1505
Kriminal Forsorgen_____ 1269

L

Labwave_____ 1568 1574
Labway_____ 1535
Lasonic_____ 1564
Lecson_____ 1267 1645
Lenco_____ 1259 1524 1537 1747
LG_____ 1175 1176 1177 1179 1180 1182 1183 1184 1185 1186
 1584 1698
Lifetec_____ 1524 1747
Linn_____ 1247 1253

Codes à 4 chiffres pour les marques de lecteur DVD

Listo _____	1553	1625							
Liteon _____	1655								
Loewe _____	1130	1175	1297	1303	1334	1366	1444		
Logik _____	1583								
Loomax _____	1471								
Lumatron _____	1259	1490	1540	1634					
Luxor _____	1233	1234	1261						

M

Magnavox _____	1298									
Marantz _____	1111	1164	1165	1166	1226	1227	1228	1238	1298	1304
	1305	1338								
Mark _____	1259	1490								
Mascom _____	1278									
Matsui _____	1206	1259	1662	1747						
Maxim _____	1453									
MBL _____	1304									
MBO _____	1560									
MbyN _____	1250	1251	1256							
Media Station _____	1599									
Medialine _____	1753									
Mediencom _____	1504	1509	1644							
Medion _____	1278	1446	1452	1479	1524	1539	1694	1747	1748	
Megatone _____	1457									
Memorex _____	1282	1524								
Mercedes-Benz _____	1209									
Metz _____	1259	1424	1425	1428	1429	1438				
Mico _____	1463	1514								
Microboss _____	1609									
Micromaxx _____	1206									
Microsoft _____	1416	1740								
Minax _____	1259									
Minowa _____	1101									
Mirai _____	1673									
Mitsubishi _____	1106	1259	1574							
Mizuda _____	1537									
Mp _____	1489									
Mpx _____	1489									

Codes à 4 chiffres pour les marques de lecteur DVD

MTC _____	1626				
Multitech _____	1278				
Mustek _____	1672	1674	1675	1676	
Mx Onda _____	1269	1463	1514	1520	1747
Myryad _____	1235				

N

NAD _____	1671				
Naim _____	1249				
Nikkei _____	1636				
Nintaus _____	1518				
Nordmende _____	1220	1221	1524		
NPG _____	1460				

O

ODYS _____	1468	1470	1515	1529	1587	1610	1611	1612	1614	1686
	1750	1751	1752	1753						
Oki _____	1233									
Onkyo _____	1687	1688	1689	1690	1691	1692	1693	1744		
Onn _____	1618									
Optim _____	1489	1645								
Optimus _____	1428	1429								
Orion _____	1203	1206	1207	1208	1257	1266				
Oritron _____	1747									
Others _____	1259	1446	1620	1621						

P

P&B _____	1537									
Pacific _____	1259	1524	1573							
Palladium _____	1206	1259	1278							
Panasonic _____	1130	1131	1132	1133	1134	1135	1136	1137	1139	1140
	1141	1142	1143	1144	1145	1146	1147	1148	1151	1152
	1153	1154	1155	1157	1158	1159	1160	1163	1210	1261
	1430									
Peacock _____	1540									

Codes à 4 chiffres pour les marques de lecteur DVD

Philips _____	1192	1230	1236	1239	1241	1242	1243	1244	1245	1270
	1285	1286	1287	1288	1289	1290	1291	1292	1293	1294
	1295	1296	1297	1298	1299	1300	1301	1302	1303	1304
	1305	1306	1307	1308	1309	1310	1311	1312	1313	1314
	1315	1316	1317	1318	1319	1320	1321	1322	1323	1324
	1325	1327	1328	1329	1330	1331	1332	1333	1335	1336
	1337	1339	1340	1341	1342	1343	1344	1345	1346	1347
	1348	1349	1351	1352	1353	1354	1355	1356	1357	1358
	1359	1360	1361	1362	1363	1364	1365	1367	1368	1533
	1622	1654	1655	1683	1684	1685	1730	1747		

Phocus_____1407

Pioneer _____	1213	1214	1215	1216	1298	1417	1418	1419	1420	1421
	1422	1423	1424	1425	1426	1427	1428	1429	1430	1431
	1432	1433	1434	1435	1436	1437	1438	1439	1440	1441

Polsat_____1568

Popcorn_____1696

Powerpoint_____1608 1609 1634

Prima_____1650

Primare_____1276

Pro2_____1452

Profilo_____1278

Proline_____1265 1269 1278 1279 1281 1283 1501 1563 1617 1618
1747

Prosonic_____1233 1257 1261 1464 1555 1556 1585 1616 1636

Provision_____1537 1620 1675

Q

Quadro_____1526 1639 1641 1701

Quelle_____1259

R

Radiola_____1298

RCA_____1416

Realmagic_____1554

Rec_____1134 1149 1504 1650

Red Star_____1278 1452 1500 1512 1527 1573 1592 1649

Reel_____1443

Reflexion_____1612

Rex_____1513

Roadstar_____1149 1259 1537 1560

Romeo_____1469

Codes à 4 chiffres pour les marques de lecteur DVD

Rotel_____ 1125 1615

Ruwido_____ 1637

S

Saba_____ 1220 1221 1233 1257 1261 1747

Salora_____ 1233 1271 1461 1497 1517 1525 1598 1610

Samsung_____ 1134 1169 1170 1171 1187 1188 1189 1190 1191 1192
 1193 1194 1195 1196 1197 1198 1199 1201 1202 1284
 1397 1398 1399 1400 1401 1402 1403 1404 1405 1723
 1724 1725 1726 1727 1728 1729 1731 1732 1733 1734
 1735 1736 1754

Sansui_____ 1206 1463 1514

Sanyo_____ 1100 1206 1233 1261 1278 1699

Scansonic_____ 1413 1414

Schaub Lorenz_____ 1234 1497 1598 1607 1634 1636 1647 1649 1702

Schneider_____ 1175 1278 1298 1304 1524 1561 1589 1590 1591 1649
 1747

Scott_____ 1309 1520 1585 1608 1609 1708 1747

SEG_____ 1100 1257 1259 1572 1574 1575 1702

Sharp_____ 1107 1108 1167 1172 1173 1174 1203 1206 1233 1259
 1711

Sherwood_____ 1175 1622 1670

Shinco_____ 1622

Siemens_____ 1278 1306

Sigma_____ 1554

Silva Schneider_____ 1278 1446 1451 1496 1497 1524 1562 1590 1591 1598
 1627 1628 1629 1630 1641 1649

SilverCrest_____ 1233 1259 1640 1702 1704 1705 1706

Sky Media_____ 1617 1660

Skyworth_____ 1650

Sm Electronic_____ 1560

Smart_____ 1259 1609

SMC_____ 1541

Sony_____ 1105 1112 1213 1306 1369 1370 1371 1372 1373 1374
 1375 1376 1377 1378 1379 1380 1381 1382 1383 1384
 1385 1386 1387 1388 1389 1390 1391 1392 1393 1394
 1395 1396 1600 1604 1715 1716 1739

Soundcolor_____ 1259 1278

Starmedia_____ 1537

Strong_____ 1568

Sunkai_____ 1449

Codes à 4 chiffres pour les marques de lecteur DVD

Supertech _____	1480				
Supratech _____	1510	1577	1662	1697	
Sweex _____	1539	1612			
Swisstec _____	1555	1617	1660		
Sylvania _____	1755				

T

Tandberg _____	1259									
Tatung _____	1278	1534								
Tboston _____	1522									
TCL _____	1220	1223								
TCM _____	1561									
Teac _____	1429	1494	1573	1671						
Techline _____	1259									
Technical _____	1233	1257								
Technics _____	1130	1131	1132	1133	1134	1135	1142	1143	1144	1145
	1150	1151	1152	1153	1154	1156	1158	1159		
Technika _____	1555	1617	1752							
Technotrend _____	1407									
Techwood _____	1233	1234	1257	1259	1261					
Telefunken _____	1220	1221	1231	1233	1234	1263				
Telestar _____	1278									
Teletech _____	1259	1283								
Televew _____	1278									
Telra _____	1278									
Tensai _____	1560	1747								
Terra _____	1232	1586								
Terratec _____	1453									
Tevion _____	1278	1636	1701	1712	1747	1749				
Theta Digital _____	1429									
Thomson _____	1218	1219	1220	1221	1222	1223	1224	1225	1263	1298
	1415	1416	1467	1617						
Tokai _____	1649	1659								
Tokaido _____	1659									
Topfield _____	1668									
Toshiba _____	1127	1130	1204	1206	1233	1596	1600	1601	1602	1603
	1604	1605	1606	1666	1695	1700	1714	1715	1716	1717
	1718	1719								
Tredex _____	1489									

Codes à 4 chiffres pour les marques de lecteur DVD

TrekStor_____1495
Triax_____1224 1568

U

Umax_____1535 1560
UMC_____1555 1617
Unibrain_____1720
Unicorn_____1475
United_____1206 1233 1257 1259 1261 1266 1538 1539 1555 1556
 1585 1621 1636 1646 1647 1649 1675
Universum_____1175 1259 1570 1597 1710

V

Vestel_____1233 1234 1257 1259 1261 1716
Vizio_____1498 1519
VOX_____1233
Voxson_____1524

W

Walkvision_____1622
Welkin_____1524
Wharfedale_____1257 1258 1267 1279 1463 1514 1659
Woxter_____1593 1632

X

Xbox_____1416
Xoro_____1484 1512 1595
Xwave_____1535

Y

Yakumo_____1578 1580 1581
Yamaha_____1134 1297 1298 1345 1350 1542 1543 1544 1545 1546
 1547 1548 1549 1550 1600 1661 1663 1666 1742 1743
Yamakawa_____1594 1746
Yelo_____1608 1609

Marques d'amplificateur

A

Accuphase_____	3198	3347			
AEG_____	3246				
Aiwa_____	3369	3371	3372	3375	3376
Akai_____	3306	3311	3339	3348	
Alba_____	3160	3179	3342		
Alco_____	3176	3253			
Amstrad_____	3160	3164	3309	3312	3377
Arcam_____	3217	3224	3228	3229	
Artdio_____	3363				
Arthur-Martin_____	3246				
Avantgarde_____	3224				

B

Bang & Olufsen_____	3271				
Blaupunkt_____	3246				
Bosch_____	3246				
Bose_____	3390	3391			
Boxford_____	3305				
Braun_____	3392				
Bush_____	3160	3190	3364		

C

Canal+ Canalsatellite_____	3224				
Casio_____	3195				
CMX/Commax_____	3282	3283	3284	3285	3288
Creek_____	3320				
Crestron_____	3216				
Crown_____	3171				
Cyrus_____	3217				

D

Daewoo_____	3125	3353			
Davis_____	3224				

Codes à 4 chiffres pour les marques d'amplificateur

Denon_____ 3107 3108 3109 3111 3112 3113 3114 3115 3116 3117
3149 3150 3151 3152 3325

Digiality_____ 3190

Diora_____ 3394

Dual_____ 3307 3314

E

Eclipse_____ 3201

Elbe_____ 3282

Elta_____ 3387

F

Ferguson_____ 3287

Fidek_____ 3321

Fisher_____ 3250 3322 3323

G

General_____ 3246

Goldbox_____ 3224

Goldstar_____ 3187

Goodmans_____ 3190 3317 3348

Gorenje_____ 3295

Grundig_____ 3180 3185 3186 3224 3244 3246 3270 3310 3365

Gryphon_____ 3224

H

Harman/Kardon_____ 3331 3332 3338

Hifidelio_____ 3225

Hitachi_____ 3204 3325 3359

I

ITT_____ 3246 3378

Codes à 4 chiffres pour les marques d'amplificateur

J

Jamo_____ 3237 3240

JVC_____ 3106 3123 3124 3125 3126 3127 3131 3132 3199 3297
3381

K

Kenwood_____ 3110 3178 3224 3313 3315 3327 3355

Kjaerulff_____ 3190

L

Lenco_____ 3190

LG_____ 3178 3182 3187 3195

Linn_____ 3217 3222 3224

Logitech_____ 3366

Luxman_____ 3153 3333 3335 3336

M

Marantz_____ 3114 3151 3152 3215 3217 3224 3235 3242

Matsui_____ 3251

MBL_____ 3241

Medion_____ 3160 3308

Mercedes-Benz_____ 3200

Meridian_____ 3224

Minowa_____ 3289

Mission_____ 3226

Musical_____ 3168

N

NAD_____ 3354

Naim_____ 3217

Nakamichi_____ 3326 3367

Niam_____ 3224

Nokia_____ 3181 3378

Codes à 4 chiffres pour les marques d'amplificateur

O

Okano _____	3345	3349								
Onkyo _____	3204	3205	3318	3356	3357	3358	3359	3360	3361	3362
Others _____	3224	3297	3373							

P

Palladium _____	3161	3202	3334	3339						
Panasonic _____	3133	3134	3135	3136	3138	3141	3143	3144		
Peacock _____	3321	3363	3366							
Philips _____	3217	3218	3219	3220	3221	3224	3230	3232	3233	3235
	3236	3238	3243	3247	3254	3255	3256	3257	3258	3259
	3260	3261	3262	3393						
Pioneer _____	3207	3208	3209	3210	3211	3212	3213	3224	3274	3275
	3276	3277	3278	3279	3280					
Primare _____	3245									
Pro-Logic _____	3346									

Q

Quad _____	3224									
Quadro _____	3304									

R

Radiola _____	3217									
Radiotone _____	3165									
Radmor _____	3231	3234	3238							
Reel _____	3281									
Rotel _____	3340	3384	3385							

S

Samsung _____	3147	3148	3154	3155	3199	3253	3269	3370	3382	
Sanyo _____	3316	3323	3324							
Schneider _____	3160	3162	3163	3164	3165	3167	3169	3170	3172	3173
	3174	3175	3177	3187	3189	3190	3191	3192	3193	3194
	3217	3224	3289	3291	3328	3339	3342	3345	3350	3368
	3374	3377	3378	3379	3383	3386				
Sharp _____	3110	3118	3119	3120						

Codes à 4 chiffres pour les marques d'amplificateur

Sherwood _____	3203	3337	3344								
Siemens _____	3160	3162	3183	3187	3223	3224	3248	3249	3252	3343	
	3345	3348	3350	3351	3352	3353					
Silva Schneider _____	3187	3188									
SilverCrest _____	3282										
Sony _____	3103	3104	3105	3112	3208	3263	3264	3265	3266	3267	
	3268										
Supertech _____	3190										

T

Teac _____	3286										
Technics _____	3133	3134	3136	3137	3139	3140	3141	3142	3145	3146	
Thomson _____	3214	3224	3272	3341							
Topfield _____	3128										
Toshiba _____	3120										

U

Uher _____	3380										
Universum _____	3155	3190	3194	3345	3348	3382					

V

Vincent _____	3290										
Vizio _____	3273										

Y

Yamaha _____	3121	3292	3293	3294	3295	3296	3297	3298	3299	3300	
	3301	3302	3303	3319	3329	3330	3388	3389			